

FIG.1




FIG. 2













FIG.3

CONNECTION TABLE FOR ENGINE CONTROL SWITCH

STATIONARY CONTACT OPERATED POSITION	CHG	SOL	IG	E	BAT	LO	ST
A							
B							
C	